



Single-phase Hybrid Inverter

USER MANUAL

HYS-8.0LV-EUG2
HYS-10.0LV-EUG2
HYS-12.0LV-EUG2

Legal Notice

Hoymiles has made every effort to ensure the accuracy and completeness of this manual. However, this manual may be changed and revised due to product enhancements or user feedback.

Hoymiles reserves the right to modify this manual without prior notice at any given time. The latest version of this manual can be found by visiting the Hoymiles official website www.hoymiles.com or scanning the QR Code below.



Warranty

Follow the installation instructions in this manual to ensure warranty compliance and reliability. The current warranty conditions can be accessed at www.hoymiles.com.

Contact Information

If you have technical queries or any questions concerning our products, please contact our support through the Hoymiles service portal:



Germany

service.de@hoymiles.com

Italy

service.it@hoymiles.com

Poland

service.pl@hoymiles.com

Other EU countries

service.eu@hoymiles.com

Spain

service.es@hoymiles.com

Netherlands

service.nl@hoymiles.com

Finland

service.fi@hoymiles.com

Australia & New Zealand

service.au@hoymiles.com

France

service.fr@hoymiles.com

Norway

service.no@hoymiles.com

Austria

service.at@hoymiles.com

Asia & Pacific

service.asia@hoymiles.com



Germany

+49 6994322186

Poland

+48 918821656

France

+33 159131589

Netherlands

+31 852736388



hoymiles.com

Contents

1	About This Manual.....	1
1.1	Purpose.....	1
1.2	Audience	1
1.3	Validity.....	1
2	Safety Information.....	2
2.1	Safety Symbols.....	2
2.2	Additional Symbols	2
2.3	Safety Instructions	4
2.4	EU Declaration of Conformity	5
3	Transportation and Storage	6
3.1	Transportation Requirements.....	6
3.2	Storage Requirements	6
4	Product Introduction	7
4.1	Product Overview.....	7
4.2	Product Dimensions	8
4.3	LED Indicators	09
4.4	Supported Power Grid	11
4.5	Working Modes	12
5	System Overview	14
5.1	Basic Diagram.....	15
5.2	Retrofit Diagram.....	17
5.3	Unacceptable Diagram.....	19
6	Installation Instructions.....	20
6.1	Unpacking.....	20
6.2	Installation Requirements	20
6.3	Installation Tools	21
6.4	Installation Steps	22
7	Electrical Connection.....	23
7.1	Recommended Cable List.....	23
7.2	Opening the Wiring Box Cover.....	24
7.3	Ground Cable Connection	24
7.4	PV Cable Connection.....	25
7.5	Battery Cable Connection.....	26
7.6	AC Cable Connection	27
7.7	Communication Cable Connection.....	28
7.7.1	Smart Meter and CT Connection	29
7.7.2	DI Connection	33
7.7.3	DO Connection.....	33
7.7.4	External Emergency Power Off Switch Connection (Optional)	33
7.7.5	BMS Connection.....	34
7.8	DTS Connection	35
7.8.1	DTS-G1.....	35
7.8.2	DTS-G3	36

7.9	Installing the Wiring Box Cover.....	37
7.10	Parallel Connection	38
8	System Commissioning.....	44
8.1	Preparation	44
8.2	System Power-on	44
9	S-Miles Cloud.....	45
9.1	Connect to the DTS.....	45
9.2	Start Commissioning.....	49
9.3	Perform System Settings	54
9.3.1	Set Advanced Parameters	54
9.3.2	Set Export Management Parameters	57
9.3.3	Set Working Mode.....	58
9.3.4	Set Dry Contact Function.....	60
9.4	Upgrade the Firmware.....	63
10	System Maintenance	64
10.1	System Power-off.....	64
10.2	Routine Maintenance	64
10.3	Troubleshooting	65
11	Decommissioning	68
11.1	Removing the Product	68
11.2	Packing the Product	68
11.3	Disposing of the Product	68
12	Technical Datasheet.....	69

1 About This Manual

1.1 Purpose

This manual provides information on the installation, electrical connections, operation, and maintenance of the HYS series inverter.

Please consider the following before installation:

- Carefully read this manual before operation.
- Keep this manual for reference.

1.2 Audience

This manual is intended for use by qualified persons only. Qualified persons must have the following skills:

- Knowledge of how an inverter works.
- Knowledge of how a battery works.
- Training in how to deal with the dangers and risks associated with the installation, maintenance, and use of electrical devices.
- Training in the installation, commissioning, and maintenance of electrical devices.
- Knowledge of and compliance with all applicable laws, standards, and directives.

1.3 Validity

This manual is valid for:


- HYS-8.0LV-EUG2
- HYS-10.0LV-EUG2
- HYS-12.0LV-EUG2

2 Safety Information

Before installing, operating, commissioning, and maintaining the inverter, please carefully read the safety rules and usage instructions in this document as failure to do so may result in safety hazards or device damage. Safety instructions in this manual cannot cover all precautions that should be taken. Please consider the actual conditions on site when performing operations. Any damage caused by a violation of the safety instructions in this manual shall not be the responsibility of Hoymiles.

2.1 Safety Symbols

Safety symbols are used in this manual as follows:

Symbol	Description
	This symbol indicates potential risks that, if not avoided, may lead to death or serious physical injury.
	This symbol indicates potential risks that, if not avoided, may lead to personal injury or device damage.
	This symbol indicates potential risks that, if not avoided, may lead to device malfunctions or financial losses.
	This symbol indicates potential risks that, if not avoided, may lead to minor injury or damage to the equipment.
	This symbol indicates an important step or tip that leads to the best results but is not safety- or damage-related.

2.2 Additional Symbols

The product label contains the following symbols with their meanings described below:

Symbol	Usage
	Caution Failure to observe any warnings contained in this manual may result in injury.
	Danger to life due to high voltages Only qualified personnel can open and maintain the inverter.
	Hot surface Burn danger due to hot surface that may exceed 60°C.
	After the inverter is turned off, wait for at least 5 minutes before opening the inverter or touching live parts.
	Treatment Electrical equipment that has reached the end of life must be collected separately and returned to an approved recycling facility to comply with the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation as national law. Return any devices you no longer need to an authorized dealer or an approved collection and recycling facility.

	CE mark The product complies with the requirements of the applicable EU directives.
	RoHS mark
	UKCA mark
	Observe the documentation Read and understand all documentation supplied with the product.
	This side up! This package must always be transported, handled, and stored in such a way that the arrows always point upwards.
	Fragile - The package/product should be handled carefully and should never be tipped over or slung.
	Keep dry! The package/product must be protected from excessive humidity and must be stored under cover.
	No more than six (6) identical packages are to be stacked on each other.

2.3 Safety Instructions

To prevent personal injury and property damage and to ensure the long-term operation of the product, read this section carefully and observe all safety information at all times. Failure to observe the prescribed instructions may potentially void the manufacturer's warranty. If in doubt, please contact Hoymiles.

DANGER

Danger to life from electric shock

- Before performing any work on the inverter, disconnect all DC and AC power from the inverter and wait for at least 5 minutes. The hazardous voltage will exist for up to 5 minutes after disconnection from the power supply.
- Never insert or remove the AC or DC connections when the inverter is running.
- Any live parts connected to battery ports cannot be touched before removing all the power from the inverter for 5 minutes, because there is still danger to life even battery voltage is lower than 60 V.
- Do not touch DC conductors or any non-isolated cable ends.
- The mounting location must be inaccessible to children.
- Never touch either the positive or negative pole of the PV connecting device. Strictly prohibit touching both at the same time.

WARNING

Risk of burns from hot surfaces

- The surface of the inverter might exceed 60°C, and touching the surface may result in burns.
- Do not touch hot surfaces before it cools down.
- Only authorized service personnel are allowed to install the inverter or perform servicing and maintenance.
- All powers, both AC and DC, should be disconnected from the inverter before attempting any maintenance, cleaning, or working on any circuits connected to the inverter.
- Attempting to service the inverter yourself may result in a risk of electric shock or fire and will void your warranty.
- Keep away from flammable and explosive materials to avoid fire disasters.
- The installation place should be away from humid or corrosive substances.
- The unit contains capacitors that remain charged to a potentially lethal voltage after the mains, battery, and PV supply have been disconnected.
- When accessing the internal circuit of inverter, wait for at least 5 minutes after disconnecting the power.

CAUTION

- The inverter has a transformerless design on the PV side. Neither positive nor negative terminals of PV panels should be grounded.
- The frames of PV panels should be grounded for safety reasons.
- Ensure that existing wiring is in good condition and no wire is undersized.
- Do not disassemble any parts of the inverter which are not mentioned in the installation.
- Authorized service personnel must use insulated tools when installing or working with this equipment.
- PV modules shall have an IEC 61730 class A rating.

NOTICE

- The minimum rated temperature of the wire used is 90°C (194°F).
- All electrical connections must be in accordance with local and national standards.
- Only with permission of the local utility grid company, the inverter can be connected to the utility grid.
- Do not open the inverter cover or change any components without authorization, otherwise the warranty commitment for the inverter will be invalid.
- Appropriate methods must be adopted to protect inverter from electrostatic discharge; any damage caused by ESD is not warranted by the manufacturer.
- Prior to the application, please read this section carefully to ensure the correct and safe application. Please keep the user manual properly.
- The manual contains no instructions for user-serviceable parts. See Warranty for instructions on obtaining service.
- If an error occurs, contact your local distributor or qualified electricians.

2.4 EU Declaration of Conformity

Hoymiles Power Electronics Inc. hereby declares that the inverter described in this document is in compliance with the basic requirements and other relevant provisions of the following directives.

- Electromagnetic Compatibility Directive 2014/30/EU (EMC)
- Low Voltage Directive 2014/35/EU (LVD)
- Restriction of the use of certain hazardous substances Directive 2011/65/EU and its amendment directives (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE)

More detailed information can be found at <https://www.hoymiles.com>.

3 Transportation and Storage

3.1 Transportation Requirements

- Place the inverters in the original packaging or specially designed transport packaging. The packaging materials should have sufficient strength and cushioning performance to prevent damage caused by collisions and squeezes during transportation.
- Secure the inverter firmly inside the packaging to avoid displacement during transportation. For large or heavy inverters, additional fixing devices may be required.
- Maintain stability and avoid sudden starts, stops, or significant oscillations during transportation.
- Observe the safety symbols on the package of the inverter before transportation.
- Pay attention to the weight of inverter. Be cautious to avoid injury when moving. Handle the inverter according to the personnel quantity required by local regulations.
- Wear protective gloves when moving the equipment by hand to prevent injuries.
- Hold the handle position and the bottom position of the inverter when lifting up the inverter. Keep the inverter horizontal in case it falls.
- Professional handling equipment should be used, and it is essential to ensure that the operators possess the requisite operational skills and experience.


3.2 Storage Requirements

- Do not unpack the inverter if it is not used immediately.
- The storage temperature should be between -40°C and 70°C , and the relative humidity should be between 5% and 95%, without condensing.
- Store inverters in a clean and dry place to protect them from dust and moisture.
- The storage place should be well ventilated to ensure air circulation and avoid overheating of the equipment.
- Do not store the products in places exposed to direct sunlight, wet by rain, or with strong electric fields.
- Do not store inverters in places with chemically corrosive substances or where there are pests and rodents.
- Inverters should be repackaged in their original packages with desiccants retained.
- To avoid personal injury or device damage, stack inverters with caution to prevent them from falling down.
- The packages should not be tilted or inverted.
- Do not place heavy objects on the inverters to prevent damage to the equipment housing or internal components.
- During the storage period, inverters should be checked regularly, and it is recommended to check the inverter once every three months. Replace the packing materials damaged by insects or rodents in a timely manner.
- If inverters have been stored for two years or longer, they must be inspected and tested by professionals before being put into use.

4 Product Introduction

4.1 Product Overview



The HYS-LV series is a high-performance single-phase hybrid inverter with excellent reliability. The intelligent EMS function supports self-consumption, economic, and backup modes for multi-scenario applications. Monitoring management through S-Miles Cloud allows users to remotely diagnose and track the system performance over time, offering superior energy production.




* The image shown here is for reference only. The actual product received may differ.

Object	Description
1	LED Indicators
2	DC Switch
3	PV Terminals
4	Communication Terminals
5	Battery Terminals
6	Grounding Bar
7	AC Terminals


4.2 Product Dimensions



4.3 LED Indicators




Indicator	Status	Explanation
SOC		Full circle LEDs on – SOC is 75-100%; battery is discharging or in standby Full circle LEDs blink – SOC is 75-100%; battery is charging
		3/4 circle LEDs on – SOC is 50-75%; battery is discharging or in standby 3/4 circle LEDs blink – SOC is 50-75%; battery is charging
		2/4 circle LEDs on – SOC is 25-50%; battery is discharging or in standby 2/4 circle LEDs blink – SOC is 25-50%; battery is charging
		1/4 circle LED on – SOC is 0-25%; battery is discharging or in standby 1/4 circle LED blinks – SOC is 0-25%; battery is charging
		Full circle LEDs off – No BMS communication




Indicator	Status	Explanation
RUN		Off – Inverter is shut down Blink 1 – Inverter is booting Blink 2 – Inverter is in bypass mode On – Inverter is turned on
PV		Off – PV voltage is low Blink 1 – PV power is low On – PV is generating power
AC		Off – Grid is disconnected and EPS is off, or a grid fault occurs Blink 1 – Grid is disconnected but EPS is on On – Grid is connected
COM		Off – Communication error of both meter and BMS Blink 1 – Communication failed to meter Blink 2 – Communication failed to BMS On – Both meter and BMS communications are normal
FAULT		Off – No fault On – A fault occurs Blink 1 – EPS port overload Blink 2 – ISO/RCD fault Blink 3 – Arc fault

4.4 Supported Power Grid


There are different ways of wiring for different grid systems. TN-S/TN-C/TN-C-S are shown as follows.



TN-S








TN-C



TN-C-S

4.5 Working Modes

Main Working Modes		
Self-consumption Mode	In the daytime, solar energy supports the loads first and surplus energy is stored in the battery. When the battery is fully charged or reaches the maximum charge power, the rest energy is fed into the grid (or limited if required). At night, the battery discharges for the loads first, and the grid will supply the loads once the battery power is not enough. In this mode, the battery cannot be charged from the grid at night.	 
		
Power flow of self-consumption mode		
Economy mode	In this mode, the time of battery charge and discharge needs to be set. Meanwhile, the battery can be forced to charge from the grid during the preset charge time. For instance, the battery could be charged or discharged according to valley or peak electricity price.	




5 System Overview

NOTICE

- This diagram is a simplified system sketch that is only intended to explain system architecture.
- Please refer to <https://www.hoymiles.com> for the compatible battery list, and the user should first contact Hoymiles for technical consultation and obtain official confirmation before installing any battery not included in the officially published list.
- Lead-acid battery is not recommended for general customers as it requires experienced installers and technicians who can fully understand the battery parameters and configure the settings and installations correctly. Please contact Hoymiles for technical support on lead-acid battery installation.

The HYS-LV series inverter can be connected to a battery and PV panels to form a PV Energy Storage System (ESS). In the event of a grid outage, it can be used as an emergency power supply (EPS) through the self-consumption of solar energy. It can form a hybrid system for a new installation or an AC coupled system to retrofit existing installations.




5.1 Basic Diagram

A. Diagram for Australia, New Zealand, South Africa, etc.

NOTICE

- This diagram is an example of application in which the neutral connects with PE in the distribution box.
- For countries such as Australia, New Zealand, South Africa, etc., please follow local wiring regulations!



Model	①	②	③	④	⑤	⑥	⑦	⑧⑨
HYS-8.0LV-EUG2	200 A/60 V DC Fuse	50 A/230 V AC Breaker	50 A/230 V AC Breaker	125 A/230 V AC Breaker	Depends on Loads	Depends on Meter	Main Breaker	30 mA RCD
HYS-10.0LV-EUG2	250 A/60 V DC Fuse	63 A/230 V AC Breaker	63 A/230 V AC Breaker	125 A/230 V AC Breaker				
HYS-12.0LV-EUG2	300 A/60 V DC Fuse	80 A/230 V AC Breaker	80 A/230 V AC Breaker	125 A/230 V AC Breaker				


NOTE

- If the battery integrates a readily accessible internal DC breaker or fuse, no additional ① DC breaker is required.
- If the generator has integrated a readily accessible internal AC breaker, then no additional ② AC breaker is required.
- ⑧⑨ 30 mA RCD is recommended but not mandatory; please comply with local regulations.

B. Diagram for Other Countries

NOTICE

- This diagram is an example of application in which the neutral is separated from the PE in the distribution box.
- For countries such as China, Germany, Italy, etc., please follow local wiring regulations!
- The back-up PE line and earthing bar must be grounded properly and effectively. Otherwise, the back-up function may be abnormal when the grid fails.



Model	①	②	③	④	⑤	⑥	⑦	⑧⑨
HYS-8.0LV-EUG2	200 A/60 V DC Fuse	50 A/230 V AC Breaker	50 A/230 V AC Breaker	125 A/230 V AC Breaker	Depends on Loads	Depends on Meter	Main Breaker	30 mA RCD
HYS-10.0LV-EUG2	250 A/60 V DC Fuse	63 A/230 V AC Breaker	63 A/230 V AC Breaker	125 A/230 V AC Breaker				
HYS-12.0LV-EUG2	300 A/60 V DC Fuse	80 A/230 V AC Breaker	80 A/230 V AC Breaker	125 A/230 V AC Breaker				

NOTE

- If the battery integrates a readily accessible internal DC breaker or fuse, no additional ① DC breaker is required.
- If the generator has integrated a readily accessible internal AC breaker, then no additional ② AC breaker is required.
- ⑧⑨ 30 mA RCD is recommended but not mandatory; please comply with local regulations.

5.2 Retrofit Diagram

The HYS-LV series inverter is compatible with any single-phase grid-connected PV inverter. With the addition of the Hoymiles hybrid inverter, the existing PV system can be retrofitted to be a PV Energy Storage System (ESS), allowing more self-consumption energy and more backup energy.

Consult with your system integrator for detailed wiring according to your requirements.

Diagram 1











Diagram 2

**NOTE**

- If there is a strong desire to use this system in off-grid mode, it is recommended to connect the PV inverter to the GEN port (Diagram 1); if not, it is recommended to connect the PV inverter to the grid port (Diagram 2).
- If a generator or a PV inverter is connected to the GEN port, there is no need to connect an additional meter.
- If a PV inverter is connected to the GRID port and the Meter-2S-G3 is used, there is no need to connect the PV inverter side smart meter. This is because the Meter-2S-G3 has two CT terminals to connect the grid side CT and the PV inverter side CT.
- If a PV inverter is connected to the GEN port, the power of the PV inverter shall be less than the rated output power of Hoymiles hybrid inverter.
- If power export management is required, the power of the PV inverter shall be less than the battery charge power. The zero-export function will be disabled after the battery is fully charged.



5.3 Unacceptable Diagram

Avoid the following installation types to prevent damage to the system or the inverter.



NOTE

The following two diagrams are acceptable if the inverters are connected in parallel.




6 Installation Instructions

6.1 Unpacking

Please ensure that none of the components listed below are missing or damaged upon receipt of the hybrid inverter.

NOTE

- The pictures below are for reference only. For details, refer to the product and accessories that you received.
- The DTS connecting line is included only when the DTS you received is the DTS-G1 series.



6.2 Installation Requirements

WARNING

- Make sure there is no electrical connection before installation.
- To avoid electric shock or other injuries, make sure that holes are not drilled over any electrical parts or plumbing installations.


NOTICE

Make sure the inverter is correctly installed according to the following list. Any incorrect installation would require a risk assessment.

- The inverter installation should be protected by shelter from direct sunlight or bad weather such as snow, rain, or lightning.
- The inverter should be installed on a solid surface that is suitable for the inverter's dimensions and weight.
- The inverter should be installed vertically or at a maximum back tilt of 15°. Leave enough space around the inverter according to the figure below.





- The inverter should be installed in an environment with good ventilation and heat dissipation conditions.
- The ambient temperature should be between -25°C and 45°C . High ambient temperatures will cause power derating of the inverter.
- The relative humidity should be less than 95%, without condensing.
- The inverter should be installed at eye level for convenient maintenance.
- The product label on the inverter should be visible after installation.
- The inverter should be installed far from flammable materials.







6.3 Installation Tools

The following tools are recommended in the installation process, and other auxiliary tools can also be used on site if necessary.



6.4 Installation Steps

Install the inverter on the wall using the provided wall-mounting bracket and expansion plug sets.

Procedure	
Step 1&2	a. Position the bracket against the wall and mark the 6 drilling hole locations. b. Drill holes with a driller, and make sure the holes are deep enough (at least 60 mm).
	 
Step 3&4	a. Place sleeves in the holes, and then tighten them. b. Fix the wall bracket with expansion screws. Please confirm that the bracket is firmly attached to the mounting surface.
	 
Step 5&6	a. Mount the inverter on the bracket. b. Tighten the screw with a torque of 1.4 N·m to secure the bracket and the inverter.
	 

7 Electrical Connection

WARNING

- Before any electrical connections, keep in mind that the inverter has dual power supplies.
- It is mandatory for the qualified personnel to wear personal protective equipment (PPE) during the electrical work.


7.1 Recommended Cable List

The following table provides the cable specifications recommended by Hoymiles. The cables used in actual installation can be larger than the recommended specifications, but cannot be smaller than the recommended specifications. Select the appropriate cables in accordance with local laws and regulations.

Cable (90°C/194°F, Copper)	Specification			Stripping Length
	HYS-8.0LV-EUG2	HYS-10.0LV-EUG2	HYS-12.0LV-EUG2	
Ground Cable	4 AWG (25 mm ²)	4 AWG (25 mm ²)	4 AWG (25 mm ²)	12-14 mm
PV Cable	10-8 AWG (6-10 mm ²)	10-8 AWG (6-10 mm ²)	10-8 AWG (6-10 mm ²)	13-14 mm
Battery Cable	1/0-2/0 (50-70 mm ²)	2/0-3/0 (70-95 mm ²)	3/0-4/0 (95-120 mm ²)	20-23 mm
GRID L/N Cable	4-2 AWG (25-35 mm ²)	4-2 AWG (25-35 mm ²)	4-2 AWG (25-35 mm ²)	17-18 mm
GRID PE Cable	6 AWG (16 mm ²)	6 AWG (16 mm ²)	6 AWG (16 mm ²)	10-12 mm
EPS L/N/PE Cable	10-8 AWG (6-10 mm ²)	8-6 AWG (10-16 mm ²)	8-6 AWG (10-16 mm ²)	17-18 mm
GEN L/N/PE Cable	10-8 AWG (6-10 mm ²)	8-6 AWG (10-16 mm ²)	8-6 AWG (10-16 mm ²)	17-18 mm
Communication Cable	24 AWG (0.2 mm ²)	24 AWG (0.2 mm ²)	24 AWG (0.2 mm ²)	8 mm

7.2 Opening the Wiring Box Cover


Procedure	
Step 1	Loosen but do not remove the 6 screws of the wiring box cover with T20 screwdriver.
Step 2	Remove the cover.



7.3 Ground Cable Connection

Cable (90°C/194°F, Copper)	Specification			Stripping Length
	HYS-8.0LV-EUG2	HYS-10.0LV-EUG2	HYS-12.0LV-EUG2	HYS-8.0/10.0/12.0LV-EUG2
Ground Cable	4 AWG (25 mm²)	4 AWG (25 mm²)	4 AWG (25 mm²)	12-14 mm

Procedure	
Step 1	Crimp the cable and ground terminal.
Step 2	Use the screw from the accessory box to fasten the cable with the Phillips screwdriver.



7.4 PV Cable Connection

⚠ WARNING


Before connecting the PV cable, please make sure all requirements listed below are followed.

- The voltage, current, and power ratings of the panels to be connected are within the allowable range of the inverter. Ensure the polarity is correct, and please refer to the technical parameters in [12 Technical Datasheet](#) for voltage and current limits.
- If the PV cables are reversely connected or if the inverter is not working properly, do not turn off the DC switch. Otherwise, it may cause a DC arc, fire, or damage to the inverter. After the PV input current drops below 0.5 A, disconnect the DC switch and adjust the polarity of the PV strings.
- Since the inverter is a transformerless structure, please do not ground the outputs of PV panels.
- Check the cable connection of the PV strings for correct polarity, and ensure that, in any case, the open-circuit voltage does not exceed the inverter input limit of 550 V.


Cable (90°C/194°F, Copper)	Specification			Stripping Length
	HYS-8.0LV-EUG2	HYS-10.0LV-EUG2	HYS-12.0LV-EUG2	HYS-8.0/10.0/12.0LV-EUG2
PV Cable	10-8 AWG (6-10 mm²)	10-8 AWG (6-10 mm²)	10-8 AWG (6-10 mm²)	13-14 mm

Procedure	
Step 1	Strip the cable insulation by 13-14 mm.
Step 2	First insert the PV cable into the terminals according to positive and negative polarity, and then gently pull the cables backward to ensure that they are firmly connected.


PV1+ PV1- PV2+ PV2-



1



2



7.5 Battery Cable Connection

This section mainly describes the cable connections on the inverter side. For the cable connections on the battery side, refer to the documents provided by the battery manufacturer.

For batteries without a built-in DC breaker, make sure that an external DC breaker is connected.

If you need to use this hybrid inverter as a grid-tied inverter, please contact Hoymiles for help.

 **WARNING**

Before connecting the battery cables, please make sure all requirements listed below are followed.

- A two-pole DC breaker with an overcurrent protection (OCP) function is compulsory to be installed between the inverter and battery. The battery may have this switch integrated. If not, an external DC switch of proper ratings should be used.
- Make sure the breaker mentioned above is in the “OFF” position.
- Check the cable connection of the battery for polarity correctness and ensure that the open-circuit voltage in any case does not exceed the input limit of 60 V.
- Check the cable connection of the battery for correct polarity, and ensure that, in any case, the open-circuit voltage does not exceed the inverter input limit of 60 V.

Before proceeding to the next step, make sure that the battery voltage is 0 V using a multimeter.

NOTICE

- Do not turn on the battery switch until all cables are properly connected.
- **The inverter is compatible with specific batteries.** For battery models that this inverter supports, please refer to the [Hoymiles compatible battery list](#).

Cable (90°C/194°F, Copper)	Specification			Stripping Length
	HYS-8.0LV-EUG2	HYS-10.0LV-EUG2	HYS-12.0LV-EUG2	HYS-8.0/10.0/12.0LV-EUG2
Battery Cable	1/0-2/0 (50-70 mm²)	2/0-3/0 (70-95 mm²)	3/0-4/0 (95-120 mm²)	20-23 mm


Procedure

Step 1


Strip the battery cable insulation by 20-23 mm.

Step 2


Use the hex wrench to unscrew the bolts, insert the battery cables into the terminals, and then tighten the bolts. Gently pull the battery cables backward to ensure that they are firmly connected.



1



2



© 2025 Hoymiles Power Electronics Inc. All rights reserved.

Hoymiles Customer Support: hoymiles.com/support/

26

7.6 AC Cable Connection

The following diagrams are examples of connecting grid cables. The GEN and EPS connection methods are similar to the grid connection. For the cable specifications of GEN and EPS, please refer to the following cable specification list.

⚠ WARNING

Before connecting the AC cables, please make sure all requirements listed below are followed.

- An independent one or two circuit breaker must be installed on the output side of the inverter to ensure safe disconnection from the grid.
- Multiple inverters cannot share one circuit breaker.
- Never connect a load between the inverter and the circuit breaker.
- Make sure that the overcurrent protection devices (OCPDs) (breakers) are turned off.
- Ensure the rated power of the EPS load does not exceed the rated output power of the inverter.
- Ensure that the starting power of inductive loads, such as air conditioners, refrigerators, and pumps, does not exceed the EPS peak power of the inverter. (The starting power of the air conditioner is at least 2 times the rated power. For details, refer to the appliance manual.) Otherwise, the inverter will stop output or even shut down with a fault alarm.

Before proceeding to the next step, make sure that the AC voltages are 0 V using a multimeter.




📌 NOTE

- The colors for L, N, and PE wires used in this manual are L-Brown, N-Blue, and PE-Yellow&Green.
- The wiring color code may vary. Please follow local laws and regulations for wiring.

Cable (90°C/194°F, Copper)	Specification			Stripping Length
	HYS-8.0LV-EUG2	HYS-10.0LV-EUG2	HYS-12.0LV-EUG2	
GRID L/N Cable	4-2 AWG (25-35 mm ²)	4-2 AWG (25-35 mm ²)	4-2 AWG (25-35 mm ²)	17-18 mm
GRID PE Cable	6 AWG (16 mm ²)	6 AWG (16 mm ²)	6 AWG (16 mm ²)	10-12 mm
EPS L/N/PE Cable	10-8 AWG (6-10 mm ²)	8-6 AWG (10-16 mm ²)	8-6 AWG (10-16 mm ²)	17-18 mm
GEN L/N/PE Cable	10-8 AWG (6-10 mm ²)	8-6 AWG (10-16 mm ²)	8-6 AWG (10-16 mm ²)	17-18 mm


Procedure

Step 1	Strip the grid L/N cable insulation by 17-18 mm. Strip the grid PE cable insulation by 10-12 mm.
Step 2	Firstly, use the slotted screwdriver to unscrew the screw on the grounding bar, insert the grid PE cable, and tighten the screw. Secondly, insert the slotted screwdriver into the terminal to press down the leaf spring, insert the L/N cable into the grid terminals, and then remove the screwdriver. Gently pull the grid L/N/PE cables backward to ensure that they are firmly connected.



7.7 Communication Cable Connection

Detailed pin functions of each port on the communication interface are as follows.



Label	Description
Parallel (CANH, CANL, 485B_1, 485A_1, 485B_2, 485A_2)	For parallel operation.
BMS (NTC+, NTC-, CANH, CANL, 485A, 485B)	For Li-ion batteries, communication is via CAN. For lead-acid batteries, the temperature is monitored via a sensor through NTC+ and NTC-.
SW_485 (ON, OFF)	120 Ohm termination resistor for parallel operation.
SW_CAN (ON, OFF)	120 Ohm termination resistor for parallel operation.
Meter (485A1, 485B1, 485A2, 485B2)	For the smart meter. One is connected to the grid side, and the other is connected to the third-party inverter.
DI (DI_A, DI_B)	Dry contact input of external bypass contactor.
+12V / GND	Reserved.
EPO_P / EPO_N	For external Emergency Power Off switch.
DO1 (NO1, COM1)	Dry contact output. The DO1 can be set to one of the functions as follows: Earth Fault Alarm, Load Control, and Generator Control.
DO2 (NO2, COM2)	Dry contact output. The DO2 will control the bypass contactor under certain logic.

7.7.1 Smart Meter and CT Connection

The smart meter and CT in the accessory box are necessary for system installation and are used to provide the operating condition of the inverter via RS485 communication.

WARNING


Before connecting the smart meter and CT, ensure that the AC cable is totally isolated from the AC power source.


NOTICE

- One smart meter can be used with only one inverter.
- One CT must be used for one smart meter and must be connected to the same phase as the smart meter power cable.
- There is a symbol (arrow) or label on the surface of CT that indicates the correct mechanical orientation of the CT on the conductor under measurement. Please identify the arrow or label before installing the CT.
- The communication cable should be a standard CAT 5 Ethernet cable.

Cable (90°C/194°F, Copper)	Specification			Stripping Length
	HYS-8.0LV-EUG2	HYS-10.0LV-EUG2	HYS-12.0LV-EUG2	
Communication Cable	24 AWG (0.2 mm ²)	24 AWG (0.2 mm ²)	24 AWG (0.2 mm ²)	8 mm

DDSU666 (CT-100 A) Connection







NOTE


- Two smart meters are required for the installation of an AC coupled system. One smart meter is in our packing box, and the other must be purchased from Hoymiles.
- If there is a communication failure, please first check if the address of the PV inverter side meter is set to 001, and check if the address of the grid side meter is set to 002.
- If a PV inverter is connected to the GEN port, there is no need to connect an additional meter.

Meter-G3 Series Connection

NOTE

- Meter-1S-G3 can be used in a hybrid system.
- Meter-2S-G3 can be used in an AC coupled system.
- This series inverter comes with Meter-1S-G3 as standard.






NOTE

- The PV inverter can be connected to the GRID port or the GEN port. This diagram takes the GRID port connection as an example.
- If a PV inverter is connected to the GRID port, Meter-2S-G3 should be used and must be purchased from Hoymiles. The grid side CT must be connected to the meter's CT1 terminal, and the PV inverter side CT must be connected to the meter's CT2 terminal.
- If a PV inverter is connected to the GEN port, Meter-2S-G3 can be used since there is no need to install a PV inverter side CT.



7.7.2 DI Connection

There is an integrated DI (DI_A, DI_B) as the dry contact input to the bypass contactor of the inverter.



7.7.3 DO Connection

The inverter has integrated a multiple-function dry contact (DO1 and DO2). The DO1 can be set to one of the functions as follows: Earth Fault Alarm, Load Control, and Generator Control. The DO2 can control the external bypass contactor if installed.



7.7.4 External Emergency Power Off Switch Connection (Optional)

An external Emergency Power Off (EPO) switch can be installed to shut down the system in case of emergency if needed.

The external EPO switch is not provided by Hoymiles and should be purchased separately. It must meet the requirements as follows.

- An ON/OFF position and an ON/OFF position indicator;
- A protection degree of NEMA 3R or above;
- The installation location should be readily accessible.

Procedure	
Step 1	Remove the jumper wires between EPO_P and EPO_N.
Step 2	Connect one end of the positive and negative wires to the EPO_P and EPO_N terminals, and connect the other end to the external EPO switch.

1

2

NOTE

If an external Emergency Power Off switch is not needed, please do not remove the jumper wires.

7.7.5 BMS Connection

BMS is used to communicate with compatible Li-ion batteries. Note that the communication cable should be a standard CAT 5 Ethernet cable. If the lead-acid battery is used to work with this inverter, the battery temperature sensor in the packing list shall be used to monitor the battery temperature.

- NOTE**
- If a battery and an EV charger are connected to the inverter simultaneously, an RJ45 coupler should be used. This is necessary because both the communication cable of the battery and the communication cable of the EV charger need to be connected to the BMS terminal of the inverter.
 - The RJ45 coupler is not included in the packing list and must be purchased separately from a third-party channel.

Procedure	
Step 1	Strip the communication cable insulation with an ethernet wire stripper, and lead the corresponding signal cables out. Insert the signal cables into the RJ45 plug in the correct order, and crimp it with a network cable crimper.
Step 2	Insert the RJ45 plug into the BMS port, and gently pull the cable backward to make sure that the plug is completely connected to the BMS port. The pin definition of BMS or battery temperature sensor is shown in the 7.7 Communication Cable Connection .


1

2


7.8 DTS Connection

7.8.1 DTS-G1


DTS-Wi-Fi-G1 Procedure	
Step 1	Remove the DTS port cover plate.
Step 2	Insert the DTS into the DTS port, and tighten the screws.
Step 3	Respectively connect the ends of the DTS connecting line to the corresponding ports.



1




2




3


DTS-Ethernet-G1 Procedure	
Step 1	Remove the DTS port cover plate.
Step 2	Insert the DTS-Ethernet into the DTS port, and tighten the screws.
Step 3	Respectively connect the ends of the DTS connecting line to the corresponding ports.
Step 4	Unscrew the swivel nut from the connector.
Step 5	a. Insert the RJ45 plug (pin definition is shown below) into the connector until there is an audible click sound. (Note that the RJ45 plug with cable sheath cannot be inserted.) b. Thread the cable of an appropriate length through the connector. c. Tighten the cable gland.




1




2



3



4



5

Pin Definition Diagram:





8-NC
7-NC
6-RX-
5-NC
4-NC
3-RX+
2-TX+
1-TX+



Tightening Torques:

- 1 ⌘ 0.8-1.5 N·m
- 2 ⌘ 0.5-0.8 N·m

Indicator	Status	Description
RUN	ON	DTS is powered on.
	OFF	DTS is not powered on.
COM	ON	Proper communication with the inverter.
	OFF	Improper communication with the inverter.
NET	ON	Proper communication with S-Miles Cloud.
	OFF	Improper communication with S-Miles Cloud.
	BLINK	Improper communication with S-Miles Cloud, but the network is connected.



7.8.2 DTS-G3

DTS-WL-G3 Procedure (LAN Mode)	
Step 1	Disassemble the DTS in sequence.
Step 2	Thread the Ethernet cable through the parts and tighten them.
1  2 	
Step 3	Remove the cover of the adapter.
Step 4	Insert the DTS into the terminal.
3  4 	

DTS-WL-G3 Procedure (Wi-Fi Mode)	
Step 1	Remove the cover of the adapter.
Step 2	Insert the DTS into the terminal.
1  2 	

Indicator	Status	Description
NET	ON	The network is connected, and communication with the S-Miles Cloud is normal.
	OFF	The network is not connected.
	BLINK	The network is connected, but communication with the S-Miles Cloud is abnormal.
COM	ON	Communication with the inverter is normal.
	OFF	Communication with the inverter is abnormal.
RUN	ON	Connected to external power supply
	OFF	Not connected to external power supply
NET & COM	BLINK	Device Upgrading

7.9 Installing the Wiring Box Cover

Procedure
After the cables are firmly and correctly connected, install the wiring box cover with a T20 screwdriver.
 

7.10 Parallel Connection

Diagram 1




Diagram 2




Diagram 3






Diagram 4




Note:

- As shown in the figure, parallel operation is performed through the parallel interface. When inverters are used in parallel, the first and the last inverters are "ON", and the others are "OFF".



- The cable used for parallel communication between two inverters cannot exceed 10 m.
- Up to 10 inverters in parallel.
- The DTS must be connected to the Master.
- The ARM version must be V2.03.05 and above, the DSP-Power version must be V1.01.12 and above, and the DSP-Safety version must be V1.01.06 and above.
- This series of inverters works with or without battery.
- The master inverter and slave inverters must be connected to the same phase. Connecting the master inverter and slave inverters to L1/L2/L3 separately will cause system errors or damage the devices. For instance,
Correct: Master - L1, Slaves - L1
Wrong: Master - L1, Slave 1 - L2, Slave 2 - L3
- For details about parallel settings and battery settings, refer to [9 S-Miles Cloud](#).
- This series of inverters with different powers can be connected in parallel.
- If the grid side current exceeds 100 A, the smart meter and CT (100 A) provided by Hoymiles will not be able to meet the current requirement. If you need other models with larger current to replace them, please contact Hoymiles sales.
- The PV inverter can be connected to the grid side. If power export management is required, the power of the PV inverter shall be less than the battery charge power. The zero-export function will be disabled after the battery is fully charged.
- For [Diagram 3](#) and [Diagram 4](#), the external bypass switch must be enabled using the S-Miles App. Detailed operation instructions are shown in [9.3.1 Set Advanced Parameters](#).

- For [Diagram 3](#) and [Diagram 4](#), please select a normally open contactor, connect it to the DI and DO2 ports of the inverter, and connect the auxiliary power supply of the contactor to the grid side. The contactor connection method is shown as follows.



Select the appropriate contactor based on the actual loads. The recommended specifications are shown as follows.

Parallel Quantity	2	3	4	5	6	7	8	9	10
Current (A)	100	150	225	250	300	400	400	500	500

8 System Commissioning

8.1 Preparation

Before the commissioning of the inverter, make sure:

- The inverter DC switch and external circuit breaker are disconnected.
- Check wiring according to [7 Electrical Connection](#).
- Check whether the grid voltage is within the permissible range through the multimeter before turning on the AC switch.
- Unused terminals must be sealed using corresponding sealing plugs.
- Nothing is left on the top of the inverter and battery.
- Cables are routed in a safe place or protected against mechanical damage.
- Warning signs and labels are intact.

8.2 System Power-on

Step 1 If the inverter is connected to the battery, turn on the battery power switch and DC breaker.

Step 2 Turn on the AC breaker between the inverter and the grid.

Step 3 Rotate the DC switch to “ON” if the inverter is connected to the PV strings.

Step 4 Check whether the inverter is operating properly through the inverter indicators status.

9 S-Miles Cloud

The S-Miles App has been developed for Hoymiles and offers the following features.

- Network configuration
- Local installation assistant
- System monitoring



Please download the S-Miles App from the Google Play Store or the App Store (iOS). The QR code above can also be scanned to download the App.

NOTE

- The DTU mentioned in this manual refers to the DTS (Data Transfer Stick).
- In a residential energy storage system, the DTU displayed in the S-Miles Cloud refers to the DTS (Data Transfer Stick).
- The screenshots shown in this manual are for reference only. Since the App version will be updated periodically, the interface displayed on your screen may differ.

9.1 Connect to the DTS

NOTE


- If you have installed DTS-G3 series, tap [here](#).
- The steps about the password are only required for the first connection.

★ DTS-G1


Step 1 Tap O&M > Toolkit.

Step 2 Tap **Via Wi-Fi** area.

Step 3 Tap **Go to set**.




Step 4 Select the wireless network of DTS and enter the default password **ESS12345**. The DTS network name consists of "DTS" and the last eight digits of the product serial number.





Step 5 Return to the App (will automatically enter the overview interface).

Step 6 Tap **Go to Settings** to change the default password.



Step 7 Enter the original password and new password, confirm the new one, and tap **Send to DTU**.



Step 8 Select the wireless network of DTS and enter the new password.



Step 9 Return to the App, and tap  **O&M** >  **Toolkit**.




★ DTS-G3

Step 1 Tap  **O&M** >  **Toolkit**.

Step 2 On the **Via Bluetooth** part, tap the DTS to be connected.


Step 3 Enter the default password **123456** and tap **Confirm**.



Step 4 Tap **Go to Settings** to change the default password.


Step 5 Enter the original password and new password, confirm the new one, and tap **Send to DTU**.

Step 6 Tap  **Toolkit** again.



Step 7 On the **Via Bluetooth** part, tap the DTS to be connected.

Step 8 Enter the new password and tap **Confirm**.




9.2 Start Commissioning

Commissioning is used to set and test a new residential energy storage system. It is a critical step to ensure that a new device and system can function properly according to the design specifications.

Step 1 Tap **O&M** > **Toolkit**.

Step 2 Tap **Commissioning**.




Step 3 Add devices

Follow the instructions below to add devices according to the actual installation, and tap **Next**.

- If a parallel system is installed, tap **Paralleling**. All slave inverters will be automatically added.

NOTE



- The DTS must be connected to the Master.
- After the slaves are connected to the Master through communication cables, they can communicate with the DTS.
- A DTS can only communicate with up to 10 inverters.




- If batteries are connected to the inverter, tap **Battery** to set battery parameters, and tap **Save**. Hoymiles batteries can be automatically identified. (The default battery type is **No battery**.)

NOTE


If Li-ion batteries are connected in parallel via the busbar, and the master battery communicates with the master inverter, enable **Multiple PCS**.



- Tap **Meter** and toggle on **Meter Settings**. Select the meter location based on the actual installation, and tap **Save**.



- If an EV charger is connected, tap **EV Charger**. You can tap **Auto Search** or scan the QR code on the label to identify the serial number (SN), and tap **Save**.




Step 4 Complete other settings

- Select the grid profile in your region, and tap **Next**.
- Select the working mode according to your actual needs, and tap **Next**. For details about working modes, refer to [9.3.3 Set Working Mode](#).
- Select **Generator** or **Inverter** according to the actual installation, and tap **Next**. (The default option is **None**.)

NOTE

If a generator is connected to the GEN port, detailed parameters are shown in [9.3.1 Set Advanced Parameters](#). After setting the parameters, tap [System Settings > Dry Contact Settings > Generator Control](#) to set its mode and corresponding parameters.


**Step 5 Complete the self-check**

You can complete or skip the self-check as required.


- If you want to complete the self-check, tap **Start Testing**.

NOTE

- Before this operation, make sure that all cables including DC cables, AC cables, and communication cables, are properly connected, and all AC and DC switches are turned on.
- If the result shows the CT is reversely connected, tap **Advanced Settings > Grid CT reverse > Enable** or **PV CT reverse > Enable**, and tap **Save**. For details, refer to [9.3.1 Set Advanced Parameters](#).
- The self-check result is accurate only when the system is connected to the grid.



- If you want to skip this step, tap **Next** > **Confirm**.




Step 6 Configure the network

NOTE

- **Go to Settings** will navigate to the new plant creation interface (haven't created a plant before the commissioning) or the homepage of the plant (have created a plant before the commissioning).
- For DTS-G1, after completing the commissioning, if you want to tap **Go to Settings**, first disconnect from the DTU Wi-Fi.

Wi-Fi Mode

- Select **Wi-Fi**, enter or select the Wi-Fi network name, enter the password, and tap **Finish**.
- Tap **Finish** after the network is successfully connected.
- Tap **Stay at Toolkit** or **Go to Settings**.




• LAN Mode

NOTE

This mode is only applicable to DTS-WL-G3, and the DTS and router are connected via LAN cable.

- Select **Ethernet** and tap **Finish**.
- Tap **Finish** after the network is successfully connected.
- Tap **Stay at Toolkit** or **Go to Settings**.




9.3 Perform System Settings

9.3.1 Set Advanced Parameters

Step 1 Tap **O&M** > **Toolkit**, and tap in the lower right corner.

Step 2 Tap **Advanced Settings** to set parameters of System, Battery, PV, Emergency Power Supply (EPS), and Generator, and tap **Save**.



★ System

Parameter	Description	Default Value
Meter Model	- For a single-phase inverter, please select "Single-phase Meter", "Three-phase Meter", "Meter_1S/1T_G3", or "Meter_2S/2T_G3" according to actual installation. - For a three-phase inverter, please select "Three-phase Meter", "Meter_1S/1T_G3", or "Meter_2S/2T_G3" according to actual installation.	No Meter
Grid CT Reverse	Enable it to get correct sampling current when the grid side CT is reversely connected.	Disable
Grid CT Ratio	Set the grid side CT ratio.	2000
PV CT Reverse	Enable it to get correct sampling current when the PV inverter side CT is reversely connected.	Disable
PV CT Ratio	Set the PV inverter side CT ratio.	2000
Display Brightness	Set the brightness of LED indicators.	10
GEN Port Mode	After the generator port is connected to the inverter or generator, select the corresponding option.	Disable
BMS485_COM_Type	- If the RS485 port is connected to the battery, please select "BMS". - If the RS485 port is connected to the microinverter DTU, please select "DTU Com".	BMS
Three-phase Unbalance	When the loads of the three-phase inverter are not balanced, enable the three-phase unbalance function. It can compensate for each load.	0

★ Battery

Parameter	Description	Default Value
Max. Discharging Power	Set the maximum discharging power.	100%
Max. Charging Power	Set the maximum charging power.	100%
Max. SOC	Set the maximum battery capacity as recommended by the battery manufacturer.	100%
Min. SOC	Set the minimum battery capacity as recommended by the battery manufacturer.	10%
Min. SOC Force Charging Power	Set the power to forcibly charge the battery when the battery SOC falls below the set minimum SOC.	200 W
Reserved SOC Force Charging Power	Set the power to charge the battery when the battery SOC falls below reserved SOC.	2%
Max. BAT Feed-in Power in Peak Time	Set the maximum value of battery feed-in power in peak time.	100%
Max. Grid Charging Power in Off-peak Time	Set the maximum power to charge the battery from the grid in off-peak time.	0 W

Parameter	Description	Default Value
Max. BAT Discharging Power in Partial Peak Time	Set the maximum value of battery discharging power in partial peak time.	100%

★ PV

Parameter	Description	Default Value
MPPT Global Scan	If the PV modules are shaded, enable this function.	Disable

★ Emergency Power Supply (EPS)

Parameter	Description	Default Value
EPS Mode	- When the EPS port is connected, you can select "EPS" or "UPS". You can select "UPS" when the load keeps power on, and the system will automatically switch between the on-grid mode and the off-grid mode under UPS mode. - EPS is characterized by continuous power supply, which means that the loads are powered by bypass under normal power supply, and the DC power will be inverted to supply the loads during power outage, maximizing energy utilization. - UPS is a kind of uninterrupted power supply which has stable voltage and frequency, and has an extremely high requirement for switching time. UPS not only operates during power outage, but also can output high quality power supply to ensure normal operation of electric equipment in case of abnormal situations such as overvoltage, undervoltage, and surge. - When the inverter is used as a PV inverter, select "Disable".	EPS
External Bypass	For inverters with an external ATS (EPS) Box, when the external bypass switch is enabled, the inverter EPS port works in the off-grid mode and will not work in the on-grid mode.	Disable
PV Only	In off-grid mode, the hybrid inverter supports operation with PV when there is no battery connection. (This function is not recommended since the system is unstable under this mode)	Disable

★ Generator

Parameter	Range
GEN Location	None/GenSide. To ensure the normal operation of the generator, please select "GenSide".
GEN Signal Setting	Manual or DI/DO. If the generator cannot be controlled by dry contact, please select "Manual". If the generator can be controlled by dry contact, please select "DI/DO".
Min. Run Time	5-60 min
Max. Run Time	6-10 hour

Parameter	Range
Protection Interval	5-60 min
Synchronize Time	1-20 min
Shutdown Delay	1-20 min
GEN Rated Power	0-20000 W
High Voltage Limit	0-280 V
Low Voltage Limit	0-180 V
High Frequency Limit	0-70 Hz
Low Frequency Limit	0-59 Hz
Max. GEN Charging Power	0-20000 W

9.3.2 Set Export Management Parameters


NOTE

- This function is enabled by default, and the default value of Max. Export Power Limit is 100%.
- ESS refers to a single energy storage inverter or a parallel system.
- The energy storage inverter cannot control the output power of other input devices connected to the grid side. It means that the feed-in power cannot be limited to 0 if other input devices are connected to the grid side.
- If no input device is connected to the grid side, Max. Export Power Limit can be set to 0-100%.

Step 1 Tap **O&M** > **Toolkit**, and tap  in the lower right corner.

Step 3 Tap **Advanced Settings** > **ESS Safety Config**, and slide your finger down to the bottom.

Step 4 Ensure **Generation Control Function (GCF)** is enabled, and set the value of Max. Export Power Limit, and tap **Save**.



- If no input device is connected to the grid side, and you do not need to limit the feed-in power, disable this function or skip this setting.
- If an input device, such as a microinverter, is connected to the grid side, and you do not need to limit the feed-in power, disable this function.

- If you need to limit the feed-in power, set Max. Export Power Limit as required.

Scenario 1: Max. Export Power Limit is 0

The feed-in power of an Energy Storage System (ESS) is 0. If an input device, such as a microinverter, is connected to the grid side, its output power cannot be controlled; it will output power according to its logic.

Scenario 2: Max. Export Power Limit is 50%

The maximum allowable feed-in power is 50% of the rated power of ESS. If an input device, such as a microinverter, is connected to the grid side, it can operate at full power, and the energy storage inverter will adjust the output of ESS in real time according to the set Max. Export Power Limit.

Scenario 3: Max. Export Power Limit is 100%

The maximum allowable feed-in power is 100% of the rated power of ESS. If an input device, such as a microinverter, is connected to the grid side, it can operate with its full power, and the energy storage inverter will adjust the output of ESS in real time according to the set Max. Export Power Limit.

Scenario 4: Max. Export Power Limit is 150%

The maximum allowable feed-in power is 150% of the rated power of ESS. If an input device, such as a microinverter, is connected to the grid side, it can operate with its full power, and the energy storage inverter will adjust the output of ESS in real time according to the set Max. Export Power Limit.

9.3.3 Set Working Mode

NOTE


Only one mode can be selected at a time.

After the commissioning, if you want to change the working mode, follow the instructions below.

Method One

Step 1 Tap  O&M >  Toolkit, and tap  Working Mode.

Step 2 Select one mode, set relevant parameters, and tap **Save**.




Method Two

Step 1 Tap  O&M >  Toolkit, tap  in the lower right corner, and tap **System Settings**.

Step 2 Tap  **Working Mode**.

Step 3 Select one mode, set relevant parameters, and tap **Save**.



★ Self-consumption Mode

In the daytime, solar energy supports the loads firstly, and surplus energy is stored in the battery. When the battery is fully charged or reaches the maximum charge power, the surplus energy is fed into the grid (or limited if required). At night, the battery discharges for the loads firstly, and the grid will supply the loads once the battery power is not enough. In this mode, battery cannot be charged from the grid at night.

The self-consumption mode can reduce the use of grid power. Solar energy is preferentially supplied to the loads, charged to the battery, and finally fed into the grid. Users can set the reserved SOC within a certain range. (A small amount of power can be reserved due to infrequent power outages.)

★ Economy Mode

In this mode, battery charging and discharging periods need to be defined. Meanwhile, the battery can be forced to charge from the grid during the preset charging time. For instance, the battery could be charged or discharged according to valley or peak electricity prices. You can set reserved SOC within a certain range (a small amount of power can be reserved due to infrequent power outages), select the type of currency you need, and set different time periods to be more flexible to save costs of electricity. Set the time period for peak, low and partial peak grid prices in different seasons or dates, and you can just add up to four time periods.

★ Backup Mode

Backup mode can be selected when the grid frequently breaks down. The battery will be forced to charge to a set capacity so that it has enough power to support the electricity consumption in daily life when the inverter is in off-grid mode. You can also set the reserved SOC within a certain range.

★ Off-grid Mode

When the system is not connected to the grid, you can choose the off-grid mode.

★ Force Charge Mode

The force charge mode can be used during the commissioning of inverter or when the battery capacity falls below the value of safety SOC. You can set the reserved SOC within a certain range. If the battery capacity is lower than the setting, the battery will be forcibly charged. And You can set the max. charging power of battery if needed. Finally, save the values you have changed.

★ Force Discharge Mode

The force discharge mode can be used during the commissioning of inverter or when the battery capacity rises above the value of safety SOC. You can set the reserved SOC within a certain range. If the battery capacity is higher than the setting, the battery will be forcibly discharged. And you can set the max. discharging power of battery if needed. Finally, save the values you have changed.

★ Peak Shaving Mode

In this mode, the Peak Meter Power (the maximum power that the inverter obtains from the grid) can be set; only when PV and battery can fully supply the loads, can the Peak Meter Power be limited. Set the Baseline SOC to ensure the normal operation of this mode. When the battery SOC is less than the Baseline SOC, the grid can supply the loads or charge the battery with an output power not higher than the Peak Meter Power; when the battery SOC is less than the reserved SOC, the battery will not be discharged.

★ Time of Use Mode

The time of use mode allows users to customize the charge and discharge time of the battery within eight periods. During the pre-set charge time, the battery will be charged from the grid at the pre-set charging power until it reaches the pre-set stop charge SOC; during the pre-set discharge time, the battery will supply power to the load and the grid at the pre-set power until the battery discharges to the pre-set stop discharge SOC. The energy storage system allows users to freely set the charge and discharge time according to the local peak and valley electricity price to maximize the benefits. For the rest of the time, the system will run in self-consumption mode by default.

9.3.4 Set Dry Contact Function


NOTE

Only one mode can be selected at a time.

Step 1 Tap O&M > Toolkit, tap in the lower right corner, and tap **System Settings**.

Step 2 Tap **Dry Contact Settings**.

Step 3 Select one mode, set relevant parameters, and tap **Save**.



★ Earth Fault Alarm

This function is used for external alarm caused by grounding insulation resistance fault or residual current fault. Disable the external alarm when the load is connected. This function is to produce alarm, not to cause tripping.

★ Load Control

Load control can be used according to individual demand. This setting is to control whether the load is working or not. There are six modes available as follows.

(1) Manual Mode

Manually turn on or turn off the dry contact.

(2) Scheduled Mode

Set the time period for the dry contact to work. The dry contact is closed during this set time and disconnected at other times.

(3) Intelligent Mode

Because the energy generated by PV fluctuates a lot, this mode is to make the dry contact avoid being turned on and off frequently. The dry contact will only be turned on when the residual energy generated by the PV exceeds the power set by the load within the set time period. You can set the minimum run time and the nominal power of the dry contact.

(4) EPS Port Smart Control

The unnecessary dry contact will be turned off in off-grid situation when the battery capacity is lower than the set SOC value. You can set the value of protection SOC if needed.

(5) EV Charger Smart Control

In this mode, whether to start the EV charger can be determined based on the total input current. When the input current is less than the value of the entrance breaker rated current minus the EV Charger rated current, the EV Charger is allowed to work; when the input current is larger than the entrance breaker rated current, shut down the EV Charger to protect the entrance breaker.

(6) Heat Pump Control

The heat pump control function allows users to add up to four runtimes. According to the set power and battery SOC, it can control the start and stop as well as the power of the SG Ready heat pump, maximizing the PV energy utilization.

Parameter	Description
Start Power	When the average feed-in power is greater than or equal to the start power, the heat pump will be started.
Shutdown Power	When the running time is greater than or equal to the minimum single runtime and the average grid input power is greater than or equal to the shutdown power, the heat pump will be shut down.
Battery Starting SOC	There is an ON/OFF option. The default option is OFF. ON: When the average feed-in power is greater than or equal to the start power or the battery SOC is greater than or equal to the battery start SOC, the heat pump will be started.
Battery Shutdown SOC	When the running time is greater than or equal to the minimum single runtime and the battery SOC is less than the battery shutdown SOC, the heat pump will be shut down.
Min. Single Runtime	The minimum single runtime of the heat pump.
Max. Single-day Runtime	There is an ON/OFF option. The default option is OFF. ON: The heat pump will be shut down when the running time of the day reaches the maximum single-day runtime; it will be started again when the starting condition is reached the next day.
Time Range	Up to 4 operating periods can be set.

★ Generator Control

(1) Exercise Mode

The generator starts regularly during the preset period to ensure the operation of the generator.

Parameter	Description
Frequency	It allows the generator to start regularly at this frequency.
Start Time	It allows the generator to start regularly at this time.
Duration	The generator will stop running after this duration.

(2) Running Mode

This mode is the off-grid operation mode of the generator, including manual mode and auto mode.

A. Manual Mode

The manual mode is used to turn on or turn off the generator manually.

B. Auto Mode

The auto mode is used to turn on or turn off the generator according to the battery capacity. The auto mode only supports generators controlled by Dry Contact. Otherwise, please select the manual mode.

Parameter	Description
GEN Start SOC	In off-grid mode, start the generator when the battery capacity is lower than the safety SOC.
GEN Shutdown SOC	In generator mode, shut down the generator when the battery capacity is higher than the safety SOC.
Quiet Time	During the quiet time, the generator is disabled. If you set this time, it will affect the normal use of electricity.

(3) Battery Charge Time

Parameter	Description
Battery Charge Time	The generator will charge the battery during the preset period. Please choose the time period when the PV power is low to avoid wasting PV power.

9.4 Upgrade the Firmware

NOTE

During the firmware upgrade, do not power off the device.


When you enter the plant overview interface, there will be a pop-up window if there is a new firmware version.

Method One

Step 1 Tap the target plant.

Step 2 Tap **Upgrade**.

Step 3 Tap **Upgrade**.




Method Two

If you have tapped **Skip** to perform other operations, you can also follow the instructions below to upgrade the firmware.

Step 1 Tap  in the lower right corner.

Step 2 Tap  **Firmware Upgrade > Upgrade**.



10 System Maintenance

10.1 System Power-off

NOTICE

Wait at least 5 minutes after the LED indicators turn off to release the internal energy.

Step 1 Stop the inverter from working via the S-Miles App.

Step 2 If the inverter is connected to the battery, disconnect the DC breaker between the inverter and the battery.

Step 3 Disconnect the AC breaker between the inverter and the grid.

Step 4 Rotate the DC switch to "OFF" if the inverter is connected to the PV strings.

Step 5 Check whether the inverter indicators are off.

10.2 Routine Maintenance

To ensure that the inverter can operate for a long time, it is recommended to perform the following maintenance items. Make sure that all maintenance items are performed after the inverter is powered off.

Check Item	Check Method	Maintenance Interval
System Cleanliness	Periodically check the heat sinks to ensure that there are no obstacles and dust.	Once every 6 months
System Operation Status	- Check whether the inverter is damaged or deformed. - Check whether there is an abnormal sound when the inverter is working. - Check whether the inverter parameters are set correctly.	Once every 6 months
Electrical Connection	- Check whether the cables are firmly connected and intact; in particular, ensure that the parts being contacted with the metal surface are not scratched. - Check whether the waterproof plugs or covers of unused ports are firmly in place.	The first inspection is 3 months after the first installation, and the subsequent inspections can be carried out once every 6 to 12 months.
Grounding Reliability	Check whether the ground cables are firmly connected.	The first inspection is 3 months after the first installation, and the subsequent inspections can be carried out once every 6 to 12 months.

10.3 Troubleshooting

When the system is in alarm, please log in to the S-Miles App to review. The possible causes and their troubleshooting are shown as follows.

Display	Possible Cause	Handling Suggestions
Grid Overvoltage	The grid voltage is higher than the permissible range.	Generally, the inverter will reconnect to the grid after the grid recovers. If the alarm occurs frequently: 1. Make sure the ESS safety configuration of the inverter is set correctly. 2. Make sure that the grid voltage in your area is stable and within the normal range. 3. Check whether the cross-sectional area of the AC cable meets the requirement. 4. If the alarm persists, contact Hoymiles technical support team.
Grid Undervoltage	The grid voltage is lower than the permissible range.	Generally, the inverter will reconnect to the grid after the grid recovers. If the alarm occurs frequently: 1. Make sure the ESS safety configuration of the inverter is set correctly. 2. Make sure that the grid voltage in your area is stable and within the normal range. 3. Check whether the AC cable is firmly in place. 4. If the alarm persists, contact Hoymiles technical support team.
Grid Overfrequency	The grid frequency is higher than the permissible range.	Generally, the inverter will reconnect to the grid after the grid recovers. If the alarm occurs frequently: 1. Make sure the ESS safety configuration of the inverter is set correctly. 2. Make sure that the grid frequency in your area is stable and within the normal range. 3. If the alarm persists, contact Hoymiles technical support team.
Grid Underfrequency	The grid frequency is lower than the permissible range.	
No Grid	The inverter detects that there is no grid connected.	Generally, the inverter will reconnect to the grid after the grid recovers. If the alarm occurs frequently: 1. Check whether the grid supply is reliable. 2. Check whether the AC cable is firmly in place. 3. Check whether the AC cable is correctly connected. 4. Check whether the AC circuit breaker is disconnected. 5. If the alarm persists, contact Hoymiles technical support team.

Display	Possible Cause	Handling Suggestions
RCD Fault	The residual leakage current is too high.	1. The alarm can be caused by high ambient humidity, and the inverter will reconnect to the grid after the environment is improved. 2. If the environment is normal, check whether the AC and DC cables are well insulated. 3. If the alarm persists, contact Hoymiles technical support team.
PV Reverse Connection	The inverter detects that the PV strings are reversely connected.	1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the string current drops below 0.5 A. 2. If the alarm persists, contact Hoymiles technical support team.
PV Undervoltage	The PV voltage is lower than the permissible range.	1. Check whether the DC cable is firmly in place. 2. Check whether there is a PV module shaded. If so, remove the shade and ensure the PV module is clean. 3. Check whether the PV module is in abnormal aging. 4. If the alarm persists, contact Hoymiles technical support team.
PV Overvoltage	The PV voltage is higher than the permissible range.	1. Check the specification and numbers of corresponding string PV modules. 2. If the alarm persists, contact Hoymiles technical support team.
Over Temperature	The temperature inside the inverter is higher than the permissible range.	1. Make sure that the installation complies with the instructions from the User Manual. 2. Check whether the alarm "Fan Fault" occurs. If so, replace the faulty fan. 3. If the alarm persists, contact Hoymiles technical support team.
ISO Fault	The insulation impedance of the PV string to the ground is too low.	1. Use a multimeter to determine if the resistance between the earth and the inverter frame is close to zero. If not, please ensure that the connection is good. 2. If the humidity is too high, an isolation fault may occur. Attempt to restart the inverter. If the fault persists, check it again when the weather turns fine. 3. Check the resistance to ground from the PV module/cable. Take corrective measures in case of leading to a short circuit or damaged insulation layer. 4. If the alarm persists, contact Hoymiles technical support team.

Display	Possible Cause	Handling Suggestions
Arc Fault	The inverter detects that there is an arc fault.	1. Disconnect the DC switch and check whether DC cables are damaged and whether the wiring terminals are loose or in poor contact. If so, take corresponding corrective measures. 2. After taking corresponding measures, reconnect the DC switch. 3. If the alarm persists, contact Hoymiles technical support team.
EPS Load Overpower	The EPS load power is higher than the permissible range.	1. Reduce the power of EPS loads, or remove some EPS loads. The inverter will restart automatically. 2. If the alarm persists, contact Hoymiles technical support team.
Meter Reverse Connection	The inverter detects that the Meter or CT is reversely connected.	1. Make sure that the installation complies with the instructions from the User Manual. 2. If the alarm persists, contact Hoymiles technical support team.
Meter Communication Fault	The inverter detects that there is a meter communication fault.	1. Check whether the Meter communication cable and terminal are abnormal. 2. Reconnect the Meter communication cable. 3. If the alarm persists, contact Hoymiles technical support team.
Battery Reverse Connection	The inverter detects that the battery wirings are reversely connected.	1. Check the battery for polarity correctness, and correct it if necessary. 2. If the alarm persists, contact Hoymiles technical support team.
Battery Voltage Fault	The battery voltage is higher than the permissible range.	1. Check if the battery input voltage is within the normal range. 2. If the alarm persists, contact Hoymiles technical support team.
BMS Communication Fault	The inverter detects that there is a BMS communication fault.	1. Check whether the BMS communication cable and terminal are abnormal. 2. Reconnect the BMS communication cable. 3. If the alarm persists, contact Hoymiles technical support team.
BMS Battery Alarm	The inverter detects that there is a battery fault from BMS.	Try to restart the battery. If the fault persists, contact the battery manufacturer.
BMS Battery Fault	The inverter detects that there is a battery fault from BMS.	Try to restart the battery. If the fault persists, contact the battery manufacturer.
Relay Self-check Fault	The inverter detects that there is a relay self-check fault.	Try to restart the inverter. If the fault persists, contact Hoymiles technical support team.

11 Decommissioning

11.1 Removing the Product

Step 1 Power off the product as described in [10.1 System Power-off](#).

Step 2 Disconnect all cables.

Step 3 Remove the DTS and the smart meter.

Step 4 Remove the inverter from the wall, and remove the bracket if necessary.

11.2 Packing the Product

If the original package is available, put the product and its accessories into the package and keep it in a dry and proper place.

If the original package is not available, put the product and its accessories into a suitable package. The package should be easy to remove, can bear the weight of the product, and can be sealed properly.

11.3 Disposing of the Product

If the inverter can not be used and needs to be disposed of, dispose of the inverter and its accessories in accordance with the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE).

In accordance with the WEEE and its implementation in national law, the electrical devices must be collected separately and recycled in an environmentally responsible manner. We recommend that you return your used device to your dealer or obtain information regarding a local, authorized collection and disposal system. Failure to comply with this EU Directive may result in a negative impact on the environment.

12 Technical Datasheet

Model	HYS-8.0LV-EUG2		HYS-10.0LV-EUG2		HYS-12.0LV-EUG2	
Battery						
Battery type	Li-ion/Lead-acid					
Battery voltage range (V)	40-60					
Max. charge/discharge current (A)	160/160		200/200		240/240	
Max. charge/discharge power (W)	8000/8000		10000/10000		12000/12000	
Charging strategy for Li-ion battery	Self-adaption to BMS					
Charging curve	3 Stages/Equalization					
External temperature sensor	Optional					
Communication	CAN					
PV Input						
Recommended max. PV power (W)	10400		13000		15600	
Max. input voltage (V) ⁽¹⁾	550					
Rated voltage (V)	360					
Start-up voltage (V)	150					
MPPT voltage range (V)	125-500					
Max. input current (A)	32/32		32/32		32/32	
Max. short circuit current (A)	40/40		40/40		40/40	
MPPT number/Max. input strings number	2/4		2/4		2/4	
AC Input and Output (On-grid)						
Rated output power (W)	8000		10000		12000	
Max. output apparent power (VA)	8800		11000		13200	
Max. input power (W)	23000		23000		23000	
Grid form	L/N/PE					
Rated AC output voltage/Range (V)	220/230, 154-276					
Rated grid frequency (Hz)	50/60					
Max. output current (A)	38.3		47.8		57.4	
Max. input current (A)	100		100		100	
Power factor	>0.99 (0.8 leading ... 0.8 lagging)					
THDi (@rated output)	<3%					
AC Output (Off-grid)						
Rated output power (W)	8000		10000		12000	
Max. output apparent power (VA)	16000, 10s		20000, 10s		23000, 10s	
Back-up switch time (ms)	<10					
Grid form	L/N/PE					
Rated output voltage (V)	220/230					
Rated output frequency (Hz)	50/60					
Max. continuous output current (A)	34.8		43.5		52.2	
THDv (@linear load)	<3%					
Efficiency						
MPPT efficiency	99.9%		99.9%		99.9%	
Max. efficiency	97.6%		97.6%		97.6%	
EU efficiency	97.0%		97.0%		97.0%	
Max. battery discharge to AC efficiency	95.0%		95.0%		95.0%	
Protection						
Anti-islanding protection	Integrated					
PV string input reverse polarity protection	Integrated					
Insulation resistor detection	Integrated					
Residual current monitoring unit	Integrated					
AC over current protection	Integrated					
AC short current protection	Integrated					
AC overvoltage and undervoltage protection	Integrated					
Surge protection	DC Type II/AC Type III					
General						
Dimensions (W × H × D [mm])	502 × 740 × 202					
Weight (kg)	41					
Mounting	Wall mounting					
Operating temperature (°C)	-25 to +65 (>45, derating)					
Relative humidity	0-95%, no condensing					
Cooling	Smart cooling					
Topology (Solar/Battery)	Transformerless/High-frequency isolation					
Altitude (m)	≤2000					
Protection degree	IP65					
Noise (dB)	<40					
User interface	LED, APP					
Digital input/output	1 × DI, 2 × DO					
Max. parallel	10					
Communication	RS485, Wi-Fi/Ethernet/4G (optional) ⁽²⁾					
Certifications and Standards						
Grid connection standard	EN 50549, NRS 097-2-1					
Safety/EMC standard	IEC 62109-1/-2, IEC/EN 61000-6-1/-2/-3/-4					

(1) This is the maximum DC input voltage that the inverter can withstand; exceeding this limit may damage the inverter.

(2) The DTS-4G solution will be coming soon.



Hoymiles Power Electronics Inc.

 Floor 6, Building 5, 99 Housheng Road,
Gongshu District, Hangzhou 310015 P. R. China

 +86 571 2805 6101

 hoymiles.com

 service@hoymiles.com
support@hoymiles.com

